

Full Arch Immediate Loading Prerequisites

When requesting a wax-up and PMMA design, we will need various files based on your patient's specific case to ensure the best quality for both temporary and permanent restorations.

Instructions Based on Occlusal Stoppers Availability:

- **If the patient has sufficient occlusal stoppers:** Provide a CBCT scan, intraoral scans, and patient photos.
- **If the patient lacks enough occlusal stoppers** (e.g., fewer than 4 remaining teeth, mobile teeth, etc.): Submit intraoral scans of the patient's arch both with and without the partial denture, as well as a dual scan with the partial denture in place. Ensure the partial denture contains no metal to prevent scatter in the scan.
- **If the patient is edentulous:** A dual scan of both the upper and lower arches is required, making sure the dentures correctly register the bite. Additionally, patient photos should be provided.